

CPX 4120

3 Modes 4 - 7 - 11

4 Ch

Channel	Function	Value	Description
1	Red	0 --> 255	0% to 100% Red LEDs
2	Green	0 --> 255	0% to 100% Green LEDs
3	Blue	0 --> 255	0% to 100% Blue LEDs
4	White	0 --> 255	0% to 100% White LEDs

7 Ch

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Strobe	0 --> 9	Safe
		10 --> 255	0 Hz to 20Hz Strobe
3	Color Macro	0 --> 255	Colour Macro Change
4	Red	0 --> 255	0% to 100% Red LEDs
5	Green	0 --> 255	0% to 100% Green LEDs
6	Blue	0 --> 255	0% to 100% Blue LEDs
7	White	0 --> 255	0% to 100% White LEDs

11 Ch

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Strobe	0 --> 9	Safe
		10 --> 255	0 Hz to 20Hz Strobe
3	Color Macro	0 --> 255	Colour Macro Change
4	Red	0 --> 255	0% to 100% Head 1 Red LEDs
5	Green	0 --> 255	0% to 100% Head 1 Green LEDs
6	Blue	0 --> 255	0% to 100% Head 1 Blue LEDs
7	White	0 --> 255	0% to 100% Head 1 White LEDs
8	Red	0 --> 255	0% to 100% Head 2 Red LEDs
9	Green	0 --> 255	0% to 100% Head 2 Green LEDs
10	Blue	0 --> 255	0% to 100% Head 2 Blue LEDs
11	White	0 --> 255	0% to 100% Head 2 White LEDs