

Archiline 1

5 Modes 1 - 3 - 4 - 7 - 10

1 Ch

Channel	Function	Value	Description
1	Different Colors	0 --> 255	0 = Off , 7 --> 255 = Different Colors Macros

3 Ch

Channel	Function	Value	Description
1	Red	0 --> 255	0% to 100% Red LEDs
2	Green	0 --> 255	0% to 100% Green LEDs
3	Blue	0 --> 255	0% to 100% Blue LEDs

4 Ch

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Red	0 --> 255	0% to 100% Red LEDs
3	Green	0 --> 255	0% to 100% Green LEDs
4	Blue	0 --> 255	0% to 100% Blue LEDs

7 Ch

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Red	0 --> 255	0% to 100% Red LEDs
3	Green	0 --> 255	0% to 100% Green LEDs
4	Blue	0 --> 255	0% to 100% Blue LEDs

5	Color Macro	0	None
		20 --> 23	Red
		24 --> 27	Green
		28 --> 31	Blue
		32 --> 35	Yellow
		36 --> 39	Cyan
		40 --> 43	Magenta
		44 --> 47	White
		48 --> 51	Orange
		52 --> 55	Pink
		56 --> 59	Violet
		60 --> 63	Aquamarine
		64 --> 67	Sky Blue
		68 --> 71	Full White
		72 --> 75	Cool White
		76 --> 79	White
		80 --> 83	White 3200
		84 --> 87	White 2500
		88 --> 91	Yellow 2
		92 --> 95	Straw
		96 --> 99	Orange 2
		100 --> 103	Light Rose
		104 --> 107	Dark Pink
		108 --> 111	Magenta 2
		112 --> 115	Green 2
		116 --> 119	Med Blue Green
		120 --> 123	Dark Blue
		124 --> 127	Bright Pink
		128 --> 131	Medium Blue
		132 --> 135	Golden Amber
		136 --> 139	Deep Golden Amber
		140 --> 143	Pale Lavender
		144 --> 147	Apricot
148 --> 151	Dark Lavender		
152 --> 155	Chocolate		
156 --> 159	Just Blue		
160 --> 163	Surprise Pink		
164 --> 167	Scarlet		
168 --> 171	Surprise Peach		
172 --> 175	Fire		
176 --> 179	English Rose		
180 --> 183	Mauve		
184 --> 187	Bright Blue		
188 --> 191	Alice Blue		
192 --> 195	Rose Indigo		
196 --> 199	Urban Blue		
200 --> 203	Cool Blue		
204 --> 207	Light Salmon		
208 --> 211	Mayan Sun		
212 --> 215	Cherry Rose		
216 --> 219	Flesh Pink		
220 --> 223	Skelton Exotic Sangria		
224 --> 255	Amber		
6	Different Colors	0 --> 255	0 = Off , 7 --> 255 = Different Colors Macros
7	Strobe	0 --> 255	Slow to Fast Strobe

10 Ch

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Red	0 --> 255	0% to 100% Red LEDs
3	Green	0 --> 255	0% to 100% Green LEDs
4	Blue	0 --> 255	0% to 100% Blue LEDs
5	Color Macro	0	None
		20 --> 23	Red
		24 --> 27	Green
		28 --> 31	Blue
		32 --> 35	Yellow
		36 --> 39	Cyan
		40 --> 43	Magenta
		44 --> 47	White
		48 --> 51	Orange
		52 --> 55	Pink
		56 --> 59	Violet
		60 --> 63	Aquamarine
		64 --> 67	Sky Blue
		68 --> 71	Full White
		72 --> 75	Cool White
		76 --> 79	White
		80 --> 83	White 3200
		84 --> 87	White 2500
		88 --> 91	Yellow 2
		92 --> 95	Straw
		96 --> 99	Orange 2
		100 --> 103	Light Rose
		104 --> 107	Dark Pink
		108 --> 111	Magenta 2
		112 --> 115	Green 2
		116 --> 119	Med Blue Green
		120 --> 123	Dark Blue
		124 --> 127	Bright Pink
		128 --> 131	Medium Blue
		132 --> 135	Golden Amber
		136 --> 139	Deep Golden Amber
		140 --> 143	Pale Lavender
		144 --> 147	Apricot
		148 --> 151	Dark Lavender
152 --> 155	Chocolate		
156 --> 159	Just Blue		
160 --> 163	Surprise Pink		
164 --> 167	Scarlet		
168 --> 171	Surprise Peach		
172 --> 175	Fire		
176 --> 179	English Rose		
180 --> 183	Mauve		

		184 --> 187	Bright Blue
		188 --> 191	Alice Blue
		192 --> 195	Rose Indigo
		196 --> 199	Urban Blue
		200 --> 203	Cool Blue
		204 --> 207	Light Salmon
		208 --> 211	Mayan Sun
		212 --> 215	Cherry Rose
		216 --> 219	Flesh Pink
		220 --> 223	Skelton Exotic Sangria
		224 --> 255	Amber
6	Different Colors	0 --> 255	0 = Off , 7 --> 255 = Different Colors Macros
7	Strobe	0 --> 255	Slow to Fast Strobe
8	Auto Program	0 --> 8	Safe
		9 --> 10	Macro 1
		11 --> 20	Macro 2
		21 --> 30	Macro 3
		31 --> 40	Macro 4
		41 --> 50	Macro 5
		51 --> 60	Macro 6
		61 --> 70	Macro 7
		71 --> 80	Macro 8
		81 --> 90	Macro 9
		91 --> 100	Macro 10
		101 --> 110	Macro 11
		111 --> 120	Macro 12
		121 --> 130	Macro 13
		131 --> 140	Macro 14
		141 --> 150	Macro 15
		151 --> 160	Macro 16
		161 --> 170	Macro 17
		171 --> 180	Macro 18
		181 --> 190	Macro 19
200 --> 255	Macro 20		
9	Speed	0 --> 255	Program Speed when Enabled
10	Dimmer Mode	0 --> 49	Safe
		50 --> 99	Dimmer Mode 1
		100 --> 149	Dimmer Mode 2
		150 --> 199	Dimmer Mode 3
		200 --> 255	Dimmer Mode 4