

Sparkly Wash 37

3 Modes 14 - 25 -30

| |
|-------------|
| 14 Channels |
|-------------|

| Channel | Function | Value | Description |
|-------------|-----------------------|-------------|----------------------------|
| 1 | Strobe | 0 --> 19 | Strobe Off |
| | | 20 --> 24 | Strobe On |
| | | 25 --> 64 | Fast to Slow Strobe |
| | | 65 --> 69 | Strobe On |
| | | 70 --> 84 | Fast to Slow Open Pulse |
| | | 85 --> 89 | Strobe On |
| | | 90 --> 104 | Fast to Slow Close Pulse |
| | | 105 --> 109 | Strobe On |
| | | 110 --> 124 | Fast to Slow Random Strobe |
| | | 125 --> 129 | Strobe On |
| | | 130 --> 144 | Fast to Slow Random Open |
| | | 145 --> 149 | Strobe On |
| | | 150 --> 164 | Fast to Slow Random Close |
| | | 165 --> 169 | Strobe On |
| | | 170 --> 184 | Fast to Slow Pulse |
| | | 185 --> 189 | Strobe On |
| | | 190 --> 204 | Fast to Slow Random Pulse |
| | | 205 --> 209 | Strobe On |
| | | 210 --> 224 | Fast to Slow Strobe |
| | | 225 --> 229 | Strobe On |
| 230 --> 244 | Fast to Slow Exposure | | |
| 245 --> 255 | Strobe On | | |
| 2 | Dimmer | 0 --> 255 | 0% to 100% Dimmer |
| 3 | Zoom | 0 --> 255 | 0% to 100% Zoom |
| 4 | Pan | 0 --> 255 | 540° Pan |
| 5 | Pan Fine | 0 --> 255 | Pan Fine |
| 6 | Tilt | 0 --> 255 | 270° Tilt |
| 7 | Tilt Fine | 0 --> 255 | Tilt Fine |
| 8 | Control | 0 | Safe |
| | | 10 --> 14 | Reset ALL |
| | | 15 -> 39 | Safe |
| | | 40 --> 44 | P/T Normal |
| | | 45 --> 49 | P/T Fast |
| | | 50 --> 54 | P/T Slow |
| | | 55 --> 255 | Fan Fast |

| | | | |
|-------------|----------------------------|-------------|-----------------------|
| 9 | Color Macro | 0 --> 9 | Open |
| | | 10 --> 14 | Red |
| | | 15 --> 19 | Green |
| | | 20 --> 24 | Blue |
| | | 25 --> 29 | White |
| | | 30 --> 34 | 2300 |
| | | 35 --> 39 | 2500 |
| | | 40 --> 44 | 2700 |
| | | 45 --> 49 | 3000 |
| | | 50 --> 54 | 3200 |
| | | 55 --> 59 | 3300 |
| | | 60 --> 64 | 3700 |
| | | 65 --> 69 | 4300 |
| | | 70 --> 74 | 4500 |
| | | 75 --> 79 | 4600 |
| | | 80 --> 84 | 5000 |
| | | 85 --> 89 | 5500 |
| | | 90 --> 94 | 5600 |
| | | 95 --> 99 | 6500 |
| | | 100 --> 104 | Light Yellow |
| | | 105 --> 109 | Apple Green |
| | | 110 --> 114 | Pink |
| | | 115 --> 119 | Orange |
| | | 120 --> 124 | Deep Orange |
| | | 125 --> 129 | UV |
| 130 --> 134 | Open | | |
| 135 --> 174 | Fast to Slow CW Scroll | | |
| 175 --> 179 | Stop | | |
| 180 --> 219 | Slow to Fast CCW Scroll | | |
| 220 --> 224 | Open | | |
| 225 --> 255 | Fast to Slow Random Colors | | |
| 10 | Red | 0 --> 255 | 0% to 100% Red LEDs |
| 11 | Green | 0 --> 255 | 0% to 100% Green LEDs |
| 12 | Blue | 0 --> 255 | 0% to 100% Blue LEDs |
| 13 | White | 0 --> 255 | 0% to 100% White LEDs |
| 14 | Color Change | 0 --> 7 | Open |
| | | 8 --> 39 | Red to Yellow |
| | | 40 --> 71 | Yellow to Green |
| | | 72 --> 103 | Green to Cyan |
| | | 104 --> 135 | Cyan to Blue |
| | | 136 --> 167 | Blue to Magenta |
| | | 168 --> 199 | Magenta to Red |
| | | 200 --> 231 | Red to White |
| | | 232 --> 255 | Scroll |
| 0 --> 255 | Index | | |

| |
|-------------|
| 25 Channels |
|-------------|

| Channel | Function | Value | Description |
|-------------|-----------------------|-------------|----------------------------|
| 1 | Strobe | 0 --> 19 | Strobe Off |
| | | 20 --> 24 | Strobe On |
| | | 25 --> 64 | Fast to Slow Strobe |
| | | 65 --> 69 | Strobe On |
| | | 70 --> 84 | Fast to Slow Open Pulse |
| | | 85 --> 89 | Strobe On |
| | | 90 --> 104 | Fast to Slow Close Pulse |
| | | 105 --> 109 | Strobe On |
| | | 110 --> 124 | Fast to Slow Random Strobe |
| | | 125 --> 129 | Strobe On |
| | | 130 --> 144 | Fast to Slow Random Open |
| | | 145 --> 149 | Strobe On |
| | | 150 --> 164 | Fast to Slow Random Close |
| | | 165 --> 169 | Strobe On |
| | | 170 --> 184 | Fast to Slow Pulse |
| | | 185 --> 189 | Strobe On |
| | | 190 --> 204 | Fast to Slow Random Pulse |
| | | 205 --> 209 | Strobe On |
| | | 210 --> 224 | Fast to Slow Strobe |
| | | 225 --> 229 | Strobe On |
| 230 --> 244 | Fast to Slow Exposure | | |
| 244 --> 255 | Strobe On | | |
| 2 | Dimmer | 0 --> 255 | 0% to 100% Dimmer |
| 3 | Zoom | 0 --> 255 | 0% to 100% Zoom |
| 4 | Pan | 0 --> 255 | 540° Pan |
| 5 | Pan Fine | 0 --> 255 | Pan Fine |
| 6 | Tilt | 0 --> 255 | 270° Tilt |
| 7 | Tilt Fine | 0 --> 255 | Tilt Fine |
| 8 | Control | 0 | Safe |
| | | 10 --> 14 | Reset ALL |
| | | 15 --> 39 | Safe |
| | | 40 --> 44 | P/T Normal |
| | | 45 --> 49 | P/T Fast |
| | | 50 --> 54 | P/T Slow |
| | | 55 --> 255 | Fan Fast |

| | | | |
|-------------|----------------------------|-------------|-----------------------|
| 9 | Color Macro | 0 --> 9 | Open |
| | | 10 --> 14 | Red |
| | | 15 --> 19 | Green |
| | | 20 --> 24 | Blue |
| | | 25 --> 29 | White |
| | | 30 --> 34 | 2300 |
| | | 35 --> 39 | 2500 |
| | | 40 --> 44 | 2700 |
| | | 45 --> 49 | 3000 |
| | | 50 --> 54 | 3200 |
| | | 55 --> 59 | 3300 |
| | | 60 --> 64 | 3700 |
| | | 65 --> 69 | 4300 |
| | | 70 --> 74 | 4500 |
| | | 75 --> 79 | 4600 |
| | | 80 --> 84 | 5000 |
| | | 85 --> 89 | 5500 |
| | | 90 --> 94 | 5600 |
| | | 95 --> 99 | 6500 |
| | | 100 --> 104 | Light Yellow |
| | | 105 --> 109 | Apple Green |
| | | 110 --> 114 | Pink |
| | | 115 --> 119 | Orange |
| | | 120 --> 124 | Deep Orange |
| | | 125 --> 129 | UV |
| 130 --> 134 | Open | | |
| 135 --> 174 | Fast to Slow CW Scroll | | |
| 175 --> 179 | Stop | | |
| 180 --> 219 | Slow to Fast CCW Scroll | | |
| 220 --> 224 | Open | | |
| 225 --> 255 | Fast to Slow Random Colors | | |
| 10 | Red | 0 --> 255 | 0% to 100% Red LEDs |
| 11 | Green | 0 --> 255 | 0% to 100% Green LEDs |
| 12 | Blue | 0 --> 255 | 0% to 100% Blue LEDs |
| 13 | White | 0 --> 255 | 0% to 100% White LEDs |
| 14 | Color Change | 0 --> 7 | Open |
| | | 8 --> 39 | Red to Yellow |
| | | 40 --> 71 | Yellow to Green |
| | | 72 --> 103 | Green to Cyan |
| | | 104 --> 135 | Cyan to Blue |
| | | 136 --> 167 | Blue to Magenta |
| | | 168 --> 199 | Magenta to Red |
| | | 200 --> 231 | Red to White |
| | | 232 --> 255 | Scroll |
| 0 --> 255 | Index | | |

| | | | |
|-------------|--------------------|-------------|---------|
| 15 | LED Gobo | 0 --> 4 | Open |
| | | 5 --> 9 | Gobo 1 |
| | | 10 --> 14 | Gobo 2 |
| | | 15 --> 19 | Gobo 3 |
| | | 20 --> 24 | Gobo 4 |
| | | 25 --> 29 | Gobo 5 |
| | | 30 --> 34 | Gobo 6 |
| | | 35 --> 39 | Gobo 7 |
| | | 40 --> 44 | Gobo 8 |
| | | 45 --> 49 | Gobo 9 |
| | | 50 --> 54 | Gobo 10 |
| | | 55 --> 59 | Gobo 11 |
| | | 60 --> 64 | Gobo 12 |
| | | 65 --> 69 | Gobo 13 |
| | | 70 --> 74 | Gobo 14 |
| | | 75 --> 79 | Gobo 15 |
| | | 80 --> 84 | Gobo 16 |
| | | 85 --> 89 | Gobo 17 |
| | | 90 --> 94 | Gobo 18 |
| | | 95 --> 99 | Gobo 19 |
| | | 100 --> 104 | Gobo 20 |
| | | 105 --> 109 | Gobo 21 |
| | | 110 --> 114 | Gobo 22 |
| | | 115 --> 119 | Gobo 23 |
| | | 120 --> 124 | Gobo 24 |
| | | 125 --> 129 | Gobo 25 |
| | | 130 --> 134 | Gobo 26 |
| | | 135 --> 139 | Gobo 27 |
| | | 140 --> 144 | Gobo 28 |
| | | 145 --> 149 | Gobo 29 |
| | | 150 --> 154 | Gobo 30 |
| | | 155 --> 159 | Gobo 31 |
| | | 160 --> 164 | Gobo 32 |
| 165 --> 169 | Gobo 33 | | |
| 170 --> 174 | Gobo 34 | | |
| 175 --> 179 | Gobo 35 | | |
| 180 --> 184 | Gobo 36 | | |
| 185 --> 189 | Gobo 37 | | |
| 190 --> 194 | Gobo 38 | | |
| 195 --> 199 | Gobo 39 | | |
| 200 --> 204 | Gobo 40 | | |
| 205 --> 224 | Gobo Change Slower | | |
| 225 --> 234 | Stop | | |
| 235 --> 255 | Gobo Change Faster | | |

| | | | |
|----|------------------|-------------|-----------------------------|
| 16 | Effect | 0 --> 4 | No Effect |
| | | 5 --> 34 | Effect 1 |
| | | 35 --> 64 | Effect 2 |
| | | 65 --> 94 | Effect 3 |
| | | 95 --> 124 | Effect 4 |
| | | 125 --> 154 | Effect 5 |
| | | 155 --> 184 | Effect 6 |
| | | 185 --> 255 | 1 min Auto Change |
| 17 | Effect Speed | 0 --> 255 | 0% to 100% Effect Speed |
| 18 | Effect Fade | 0 --> 255 | 0% to 100% Effect Fade |
| 19 | Effect Red | 0 --> 255 | 0% to 100% Red LEDs |
| 20 | Effect Green | 0 --> 255 | 0% to 100% Green LEDs |
| 21 | Effect Blue | 0 --> 255 | 0% to 100% Blue LEDs |
| 22 | Effect White | 0 --> 255 | 0% to 100% White LEDs |
| 23 | Effect Dimmer | 0 --> 255 | 0% to 100% Effect Dimmer |
| 24 | Effect Backlight | 0 --> 255 | 0% to 100% Backlight Dimmer |
| 25 | Reserved | 0 --> 255 | Reserved |

| |
|--------------------|
| 30 Channels |
|--------------------|

| Channel | Function | Value | Description |
|-------------|-----------------------|-------------|----------------------------|
| 1 | Strobe | 0 --> 19 | Strobe Off |
| | | 20 --> 24 | Strobe On |
| | | 25 --> 64 | Fast to Slow Strobe |
| | | 65 --> 69 | Strobe On |
| | | 70 --> 84 | Fast to Slow Open Pulse |
| | | 85 --> 89 | Strobe On |
| | | 90 --> 104 | Fast to Slow Close Pulse |
| | | 105 --> 109 | Strobe On |
| | | 110 --> 124 | Fast to Slow Random Strobe |
| | | 125 --> 129 | Strobe On |
| | | 130 --> 144 | Fast to Slow Random Open |
| | | 145 --> 149 | Strobe On |
| | | 150 --> 164 | Fast to Slow Random Close |
| | | 165 --> 169 | Strobe On |
| | | 170 --> 184 | Fast to Slow Pulse |
| | | 185 --> 189 | Strobe On |
| | | 190 --> 204 | Fast to Slow Random Pulse |
| | | 205 --> 209 | Strobe On |
| | | 210 --> 224 | Fast to Slow Strobe |
| | | 225 --> 229 | Strobe On |
| 230 --> 244 | Fast to Slow Exposure | | |
| 244 --> 255 | Strobe On | | |

| | | | |
|-------------|----------------------------|-------------|------------------------|
| 2 | Dimmer | 0 --> 255 | 0% to 100% Dimmer |
| 3 | Zoom | 0 --> 255 | 0% to 100% Zoom |
| 4 | Pan | 0 --> 255 | 540° Pan |
| 5 | Pan Fine | 0 --> 255 | Pan Fine |
| 6 | Tilt | 0 --> 255 | 270° Tilt |
| 7 | Tilt Fine | 0 --> 255 | Tilt Fine |
| 8 | Control | 0 | Safe |
| | | 10 --> 14 | Reset ALL |
| | | 15 --> 39 | Safe |
| | | 40 --> 44 | P/T Normal |
| | | 45 --> 49 | P/T Fast |
| | | 50 --> 54 | P/T Slow |
| | | 55 --> 255 | Fan Fast |
| 9 | Color Macro | 0 --> 9 | Open |
| | | 10 --> 14 | Red |
| | | 15 --> 19 | Green |
| | | 20 --> 24 | Blue |
| | | 25 --> 29 | White |
| | | 30 --> 34 | 2300 |
| | | 35 --> 39 | 2500 |
| | | 40 --> 44 | 2700 |
| | | 45 --> 49 | 3000 |
| | | 50 --> 54 | 3200 |
| | | 55 --> 59 | 3300 |
| | | 60 --> 64 | 3700 |
| | | 65 --> 69 | 4300 |
| | | 70 --> 74 | 4500 |
| | | 75 --> 79 | 4600 |
| | | 80 --> 84 | 5000 |
| | | 85 --> 89 | 5500 |
| | | 90 --> 94 | 5600 |
| | | 95 --> 99 | 6500 |
| | | 100 --> 104 | Light Yellow |
| | | 105 --> 109 | Apple Green |
| | | 110 --> 114 | Pink |
| | | 115 --> 119 | Orange |
| | | 120 --> 124 | Deep Orange |
| | | 125 --> 129 | UV |
| | | 130 --> 134 | Open |
| | | 135 --> 174 | Fast to Slow CW Scroll |
| 175 --> 179 | Stop | | |
| 180 --> 219 | Slow to Fast CCW Scroll | | |
| 220 --> 224 | Open | | |
| 225 --> 255 | Fast to Slow Random Colors | | |

| | | | |
|----|---------------|-------------|--------------------------|
| 10 | Red | 0 --> 255 | 0% to 100% Red LEDs |
| 11 | Green | 0 --> 255 | 0% to 100% Green LEDs |
| 12 | Blue | 0 --> 255 | 0% to 100% Blue LEDs |
| 13 | White | 0 --> 255 | 0% to 100% White LEDs |
| 14 | Color Change | 0 --> 7 | Open |
| | | 8 --> 39 | Red to Yellow |
| | | 40 --> 71 | Yellow to Green |
| | | 72 --> 103 | Green to Cyan |
| | | 104 --> 135 | Cyan to Blue |
| | | 136 --> 167 | Blue to Magenta |
| | | 168 --> 199 | Magenta to Red |
| | | 200 --> 231 | Red to White |
| | | 232 --> 255 | Scroll |
| | | 0 --> 255 | Index |
| 15 | Group 1 Red | 0 --> 255 | 0% to 100% G1 Red LEDs |
| 16 | Group 1 Green | 0 --> 255 | 0% to 100% G1 Green LEDs |
| 17 | Group 1 Blue | 0 --> 255 | 0% to 100% G1 Blue LEDs |
| 18 | Group 1 White | 0 --> 255 | 0% to 100% G1 White LEDs |
| 19 | Group 2 Red | 0 --> 255 | 0% to 100% G2 Red LEDs |
| 20 | Group 2 Green | 0 --> 255 | 0% to 100% G2 Green LEDs |
| 21 | Group 2 Blue | 0 --> 255 | 0% to 100% G2 Blue LEDs |
| 22 | Group 2 White | 0 --> 255 | 0% to 100% G2 White LEDs |
| 23 | Group 3 Red | 0 --> 255 | 0% to 100% G3 Red LEDs |
| 24 | Group 3 Green | 0 --> 255 | 0% to 100% G3 Green LEDs |
| 25 | Group 3 Blue | 0 --> 255 | 0% to 100% G3 Blue LEDs |
| 26 | Group 3 White | 0 --> 255 | 0% to 100% G3 White LEDs |
| 27 | Group 4 Red | 0 --> 255 | 0% to 100% G4 Red LEDs |
| 28 | Group 4 Green | 0 --> 255 | 0% to 100% G4 Green LEDs |
| 29 | Group 4 Blue | 0 --> 255 | 0% to 100% G4 Blue LEDs |
| 30 | Group 4 White | 0 --> 255 | 0% to 100% G 4White LEDs |