

## LEDE 100B

1 Mode 16

Standard : 16 Ch
------------------

Channel	Function	Value	Description
1	Pan	0 --> 255	540° Pan
2	Pan Fine	0 --> 255	Pan Fine
3	Tilt	0 --> 255	270° Tilt
4	Tilt Fine	0 --> 255	Tilt Fine
5	P/T Speed	0 --> 255	0% to 100% P/T Speed
6	Shutter Function	0 --> 3	Open
		4 --> 127	Slow to Fast Pulse
		128 --> 191	Slow to Fast Fade
		192 --> 255	Random Strobe
7	Dimmer	0 --> 255	0% to 100% Dimmer
8	Color Wheel	<i>Fixed Color</i>	
		0 --> 5	Open
		6 --> 11	Color 1
		12 --> 17	Color 2
		18 --> 23	Color 3
		24 --> 28	Color 4
		29 --> 34	Color 5
		35 --> 40	Color 6
		41 --> 46	Color 7
		47 --> 51	Color 8
		52 --> 57	Color 9
		58 --> 63	Color 10
		64 --> 69	Open + Color 1
		70 --> 75	Color 1 + Color 2
		76 --> 80	Color 2 + Color 3
		81 --> 86	Color 3 + Color 4
		87 --> 92	Color 4 + Color 5
		93 --> 98	Color 5 + Color 6
		99 --> 103	Color 6 + Color 7
		104 --> 109	Color 7 + Color 8
110 --> 115	Color 8 + Color 9		
116 --> 121	Color 9 + Color 10		
122 --> 127	Color 10 + Open		

		<i>CCW Scroll</i>	
		128 --> 191	Slow to Fast CCW Scroll
		<i>CW Scroll</i>	
		192 --> 255	Slow to Fast CW Scroll
9	6 Colors Effect	0 --> 127	Open
		128 --> 255	6 Colors Effect
10	Gobo Wheel	<i>Gobos</i>	
		0 --> 9	Open
		10 --> 18	Gobo 1
		19 --> 27	Gobo 2
		28 --> 36	Gobo 3
		37 --> 45	Gobo 4
		46 --> 54	Gobo 5
		55 --> 63	Gobo 6
		64 --> 72	Gobo 7
		73 --> 81	Gobo 8
		82 --> 90	Gobo 9
		91 --> 99	Gobo 10
		100 --> 108	Gobo 11
		109 --> 117	Gobo 12
		118 --> 127	Gobo 13
		<i>CW Scroll</i>	
		128 --> 191	Slow to Fast CW Scroll
		<i>CCW Scroll</i>	
		192 --> 255	Slow to Fast CCW Scroll
		<i>Index</i>	
		0 --> 255	Index
11	Gobo Shake	0 --> 191	Slow to Fast Gobo Shake
		192 --> 255	Safe
12	Prism	0 --> 127	Open
		128 --> 255	Prism 1
13	Prism Rotation	0 --> 127	Index
		128 --> 190	Fast to Slow CCW Scroll
		191 --> 192	No Scroll
		193 --> 255	Slow to Fast CW Scroll
14	Frost	0 --> 127	Safe
		128 --> 255	Frost
15	Focus	0 --> 255	Focus
16	Reset	0 --> 127	Safe
		128 --> 255	Reset All