



Sparkly 300 B

1 Mode 16

16 Ch

Channel	Function	Value	Description
1	Colour Wheel	0 --> 4	Open
		5 --> 8	Open + Red
		9 --> 12	Red
		13 --> 17	Red + Orange
		18 --> 21	Orange
		22 --> 25	Orange + Blue
		26 --> 29	Blue
		30 --> 34	Blue + Green
		35 --> 38	Green
		39 --> 42	Green + Magenta
		43 --> 46	Magenta
		47 --> 51	Magenta + Yellow
		52 --> 55	Light Blue
		56 --> 59	Light Blue + Yellow
		60 --> 63	Yellow
		64 --> 68	Light Blue + Light Green
		69 --> 72	Light Green
		73 --> 76	Light Green + Pink
		77 --> 81	Pink
		82 --> 85	Pink + CTB 1
		86 --> 89	CTB 1
		90 --> 93	CTB 1 + Fluorescence
		94 --> 98	Fluorescence
		99 --> 102	Fluorescence + CTO 1
		103 --> 106	CTO 1
		107 --> 110	CTO 1 + CTO 2
		111 --> 115	CTO 2
		116 --> 119	CTO 2 + CTB 2
		120 --> 123	CTB 2
		124 --> 127	CTB 2 + Open
		128 --> 191	Fast to Slow CCW Scroll
		192 --> 255	Slow to Fast CW Scroll

		O --> 3	Close
		4 --> 103	Slow to Fast Strobe
		104 --> 107	Open
		108 --> 207	Fast to Slow Open Pulsation
		208 --> 212	Open
		213 --> 251	Slow to Fast Close Pulsation
		252 --> 255	Open
2	Strobe	0 --> 255	0% to 100% Dimmer
3	Dimmer	O --> 3	Open
		4 --> 7	Gobo 1
		8 --> 11	Gobo 2
		12 --> 15	Gobo 3
		16 --> 19	Gobo 4
		20 --> 23	Gobo 5
		24 --> 27	Gobo 6
		28 --> 31	Gobo 7
		32 --> 35	Gobo 8
		36 --> 39	Gobo 9
		40 --> 43	Gobo 10
		44 --> 47	Gobo 11
		48 --> 51	Gobo 12
		52 --> 55	Animation Wheel
		56 --> 71	Fast to Slow Animation
		72 --> 113	Fast to Slow CCW Rotation
4	Gobo Wheel	114 --> 117	Open
		118 --> 159	Slow to Fast CW Rotation
		160 --> 166	Slow to Fast Gobo 1 Shake
		167 --> 172	Slow to Fast Gobo 2 Shake
		173 --> 179	Slow to Fast Gobo 3 Shake
		180 --> 185	Slow to Fast Gobo 4 Shake
		186 --> 191	Slow to Fast Gobo 5 Shake
		192 --> 198	Slow to Fast Gobo 6 Shake
		199 --> 204	Slow to Fast Gobo 7 Shake
		205 --> 211	Slow to Fast Gobo 8 Shake
		212 --> 217	Slow to Fast Gobo 9 Shake
		218 --> 223	Slow to Fast Gobo 10 Shake
		224 --> 230	Slow to Fast Gobo 11 Shake
		231 --> 236	Slow to Fast Gobo 12 Shake
		237 --> 243	Animation Wheel
		244 --> 255	Slow To Fast Animation Shake
5	Prism	O --> 127	Safe
		128 --> 170	Prism 1
		171 --> 213	Prism 2
		214 --> 255	Prism 3

6	Prism 1 Rotation	0	Safe
		1 --> 127	Index
		128 --> 190	Fast to Slow CCW Rotation
		191 --> 192	Stop
		193 --> 255	Slow to Fast CW Rotation
7	Macro	0 --> 7	Safe
		8 --> 15	Macro 1
		16 --> 31	Macro 2
		32 --> 47	Macro 3
		48 --> 63	Macro 4
		64 --> 79	Macro 5
		80 --> 95	Macro 6
		96 --> 111	Macro 7
		112 --> 127	Macro 8
		128 --> 143	Macro 9
		144 --> 159	Macro 10
		160 --> 175	Macro 11
		176 --> 191	Macro 12
		192 --> 207	Macro 13
		208 --> 223	Macro 14
8	Frost	0	Safe
		1 --> 249	0% to 100% Frost
		250 --> 255	6 Colors Prism
9	Focus	0 --> 255	0% to 100% Focus
10	Pan	0 --> 255	540° Pan
11	Pan Fine	0 --> 255	Pan fine
12	Tilt	0 --> 255	270° Tilt
13	Tilt Fine	0 --> 255	Tilt Fine
14	Pan/Tilt Speed	0 --> 255	Pan/Tilt Speed
15	Reset	0 --> 25	Safe
		26 --> 76	Effect Reset
		77 --> 127	Pan/Tilt Reset
		128 --> 255	Whole Unit Reset
16	Lamp	0 --> 25	Safe
		26 --> 100	Lamp OFF
		101 --> 255	Lamp ON