

Sparkly 400 B

2 Modes 16 - 19

16 Ch

| Channel | Function | Value | Description |
|-------------|---------------|-------------|--------------------------|
| 1 | Colour Wheel | 0 --> 4 | Open |
| | | 5 --> 8 | Open + Red |
| | | 9 --> 12 | Red |
| | | 13 --> 17 | Red + Orange |
| | | 18 --> 21 | Orange |
| | | 22 --> 25 | Orange + Blue |
| | | 26 --> 29 | Blue |
| | | 30 --> 34 | Blue + Green |
| | | 35 --> 38 | Green |
| | | 39 --> 42 | Green + Magenta |
| | | 43 --> 46 | Magenta |
| | | 47 --> 51 | Magenta + Yellow |
| | | 52 --> 55 | Yellow |
| | | 56 --> 59 | Yellow + Light Blue |
| | | 60 --> 63 | Light Blue |
| | | 64 --> 68 | Light Blue + Light Green |
| | | 69 --> 72 | Light Green |
| | | 73 --> 76 | Light Green + Pink |
| | | 77 --> 81 | Pink |
| | | 82 --> 85 | Pink + CTB 1 |
| | | 86 --> 89 | CTB 1 |
| | | 90 --> 93 | CTB 1 + Fluorescence |
| | | 94 --> 98 | Fluorescence |
| | | 99 --> 102 | Fluorescence + CTO 1 |
| | | 103 --> 106 | CTO 1 |
| | | 107 --> 110 | CTO 1 + CTO 2 |
| | | 111 --> 115 | CTO 2 |
| 116 --> 119 | CTO 2 + CTB 2 | | |
| 120 --> 123 | CTB 2 | | |
| 124 --> 127 | CTB 2 + Open | | |

| | | | |
|-------------|----------------------------|-------------|------------------------------|
| 2 | Strobe | 0 --> 31 | Closed |
| | | 32 --> 63 | Open |
| | | 64 --> 95 | Slow to Fast Strobe |
| | | 96 --> 127 | Open |
| | | 128 --> 143 | Fast to Slow Open Pulsation |
| | | 144 --> 159 | Slow to Fast Close Pulsation |
| | | 160 --> 191 | Open |
| | | 192 --> 223 | Slow to Fast Random Strobe |
| | | 224 --> 255 | Open |
| 3 | Dimmer | 0 --> 255 | 0% to 100% Dimmer |
| 4 | Gobo Wheel | 0 --> 3 | Open |
| | | 4 --> 7 | Gobo 1 |
| | | 8 --> 11 | Gobo 2 |
| | | 12 --> 16 | Gobo 3 |
| | | 17 --> 21 | Gobo 4 |
| | | 22 --> 25 | Gobo 5 |
| | | 26 --> 29 | Gobo 6 |
| | | 30 --> 33 | Gobo 7 |
| | | 34 --> 37 | Gobo 8 |
| | | 38 --> 42 | Gobo 9 |
| | | 43 --> 46 | Gobo 10 |
| | | 47 --> 51 | Gobo 11 |
| | | 52 --> 55 | Gobo 12 |
| | | 56 --> 59 | Gobo 13 |
| | | 60 --> 71 | Animation Wheel |
| | | 72 --> 113 | Fast to Slow CW Rotation |
| | | 114 --> 117 | Open |
| | | 118 --> 159 | Slow to Fast CCW Rotation |
| | | 160 --> 166 | Slow to Fast Gobo 1 Shake |
| | | 167 --> 173 | Slow to Fast Gobo 2 Shake |
| | | 174 --> 178 | Slow to Fast Gobo 3 Shake |
| | | 182 --> 188 | Slow to Fast Gobo 4 Shake |
| | | 189 --> 195 | Slow to Fast Gobo 5 Shake |
| | | 196 --> 203 | Slow to Fast Gobo 6 Shake |
| | | 204 --> 210 | Slow to Fast Gobo 7 Shake |
| 211 --> 217 | Slow to Fast Gobo 8 Shake | | |
| 218 --> 224 | Slow to Fast Gobo 9 Shake | | |
| 225 --> 232 | Slow to Fast Gobo 10 Shake | | |
| 233 --> 239 | Slow to Fast Gobo 11 Shake | | |
| 240 --> 246 | Slow to Fast Gobo 12 Shake | | |
| 247 --> 255 | Slow to Fast Gobo 13 Shake | | |

| | | | |
|----|------------------|-------------|---------------------------|
| 5 | Prism | 0 --> 19 | Safe |
| | | 20 --> 39 | Prism 1 |
| | | 40 --> 59 | Prism 2 |
| | | 60 --> 79 | Prism 3 |
| | | 80 --> 99 | Prism 4 |
| | | 100 --> 119 | Prism 5 |
| | | 120 --> 139 | Prism 6 |
| | | 140 --> 159 | Prism 7 |
| | | 160 --> 179 | Prism 8 |
| | | 180 --> 199 | Prism 9 |
| | | 200 --> 219 | Prism 10 |
| | | 220 --> 255 | Prism 11 |
| 6 | Prism 1 Rotation | 0 --> 1 | Safe |
| | | 2 --> 50 | Index |
| | | 51 --> 151 | Fast to Slow CW Rotation |
| | | 152 --> 154 | Stop |
| | | 155 --> 255 | Slow to Fast CCW Rotation |
| 7 | Prism 2 Rotation | 0 --> 1 | Safe |
| | | 2 --> 50 | Index |
| | | 52 --> 151 | Fast to Slow CW Rotation |
| | | 152 --> 154 | Stop |
| | | 155 --> 255 | Slow to Fast CCW Rotation |
| 8 | Macro | 0 --> 255 | Combination Effect |
| 9 | Frost | 0 --> 255 | 0% to 100% Frost |
| 11 | 6 Colors Effect | 0 | Safe |
| | | 255 | 6 Colors Effect |
| 11 | Focus | 0 --> 255 | 0% to 100% Focus |
| 12 | Pan | 0 --> 255 | 540° Pan |
| 13 | Tilt | 0 --> 255 | 270° Tilt |
| 14 | Pan/Tilt Speed | 0 --> 255 | Pan/Tilt Speed |
| 15 | Reset | 0 --> 25 | Safe |
| | | 26 --> 76 | Effect Reset |
| | | 77 --> 127 | Pan/Tilt Reset |
| | | 128 --> 255 | Whole Unit Reset |
| 16 | Lamp | 0 --> 25 | Safe |
| | | 26 --> 100 | Lamp OFF |
| | | 101 --> 255 | Lamp ON |

| Channel | Function | Value | Description |
|-------------|---------------|-------------|------------------------------|
| 1 | Colour Wheel | 0 --> 4 | Open |
| | | 5 --> 8 | Open + Red |
| | | 9 --> 12 | Red |
| | | 13 --> 17 | Red + Orange |
| | | 18 --> 21 | Orange |
| | | 22 --> 25 | Orange + Blue |
| | | 26 --> 29 | Blue |
| | | 30 --> 34 | Blue + Green |
| | | 35 --> 38 | Green |
| | | 39 --> 42 | Green + Magenta |
| | | 43 --> 46 | Magenta |
| | | 47 --> 51 | Magenta + Yellow |
| | | 52 --> 55 | Yellow |
| | | 56 --> 59 | Yellow + Light Blue |
| | | 60 --> 63 | Light Blue |
| | | 64 --> 68 | Light Blue + Light Green |
| | | 69 --> 72 | Light Green |
| | | 73 --> 76 | Light Green + Pink |
| | | 77 --> 81 | Pink |
| | | 82 --> 85 | Pink + CTB 1 |
| | | 86 --> 89 | CTB 1 |
| | | 90 --> 93 | CTB 1 + Fluorescence |
| | | 94 --> 98 | Fluorescence |
| | | 99 --> 102 | Fluorescence + CTO 1 |
| 103 --> 106 | CTO 1 | | |
| 107 --> 110 | CTO 1 + CTO 2 | | |
| 111 --> 115 | CTO 2 | | |
| 116 --> 119 | CTO 2 + CTB 2 | | |
| 120 --> 123 | CTB 2 | | |
| 124 --> 127 | CTB 2 + Open | | |
| 2 | Strobe | 0 --> 31 | Closed |
| | | 32 --> 63 | Open |
| | | 64 --> 95 | Slow to Fast Strobe |
| | | 96 --> 127 | Open |
| | | 128 --> 143 | Fast to Slow Open Pulsation |
| | | 144 --> 159 | Slow to Fast Close Pulsation |
| | | 160 --> 191 | Open |
| | | 192 --> 223 | Slow to Fast Random Strobe |
| 224 --> 255 | Open | | |
| 3 | Dimmer | 0 --> 255 | 0% to 100% Dimmer |

| | | | |
|-------------|----------------------------|-------------|---------------------------|
| 4 | Gobo Wheel | 0 --> 3 | Open |
| | | 4 --> 7 | Gobo 1 |
| | | 8 --> 11 | Gobo 2 |
| | | 12 --> 16 | Gobo 3 |
| | | 17 --> 21 | Gobo 4 |
| | | 22 --> 25 | Gobo 5 |
| | | 26 --> 29 | Gobo 6 |
| | | 30 --> 33 | Gobo 7 |
| | | 34 --> 37 | Gobo 8 |
| | | 38 --> 42 | Gobo 9 |
| | | 43 --> 46 | Gobo 10 |
| | | 47 --> 51 | Gobo 11 |
| | | 52 --> 55 | Gobo 12 |
| | | 56 --> 59 | Gobo 13 |
| | | 60 --> 71 | Animation Wheel |
| | | 72 --> 113 | Fast to Slow CW Rotation |
| | | 114 --> 117 | Open |
| | | 118 --> 159 | Slow to Fast CCW Rotation |
| | | 160 --> 166 | Slow to Fast Gobo 1 Shake |
| | | 167 --> 173 | Slow to Fast Gobo 2 Shake |
| | | 174 --> 181 | Slow to Fast Gobo 3 Shake |
| | | 182 --> 188 | Slow to Fast Gobo 4 Shake |
| | | 189 --> 195 | Slow to Fast Gobo 5 Shake |
| | | 196 --> 203 | Slow to Fast Gobo 6 Shake |
| 204 --> 210 | Slow to Fast Gobo 7 Shake | | |
| 211 --> 217 | Slow to Fast Gobo 8 Shake | | |
| 218 --> 224 | Slow to Fast Gobo 9 Shake | | |
| 225 --> 232 | Slow to Fast Gobo 10 Shake | | |
| 233 --> 239 | Slow to Fast Gobo 11 Shake | | |
| 240 --> 246 | Slow to Fast Gobo 12 Shake | | |
| 247 --> 255 | Slow to Fast Gobo 13 Shake | | |
| 5 | Prism 1 | 0 --> 15 | Safe |
| | | 16 --> 95 | Prism 1 |
| | | 96 --> 175 | Prism 2 |
| | | 176 --> 255 | Prism 3 |
| 6 | Prism 1 Rotation | 0 --> 1 | Safe |
| | | 2 --> 50 | Index |
| | | 51 --> 151 | Fast to Slow CW Rotation |
| | | 152 --> 154 | Stop |
| | | 155 --> 255 | Slow to Fast CCW Rotation |
| 7 | Prism 2 | 0 --> 15 | Safe |
| | | 16 --> 95 | Prism 1 |
| | | 96 --> 255 | Prism 2 |
| 8 | Prism 2 Rotation | 0 --> 1 | Safe |
| | | 2 --> 50 | Index |
| | | 52 --> 151 | Fast to Slow CW Rotation |
| | | 152 --> 154 | Stop |
| | | 155 --> 255 | Slow to Fast CCW Rotation |

| | | | |
|----|-----------------|-------------|--------------------|
| 9 | Macro | 0 --> 255 | Combination Effect |
| 10 | Frost | 0 --> 255 | 0% to 100% Frost |
| 11 | 6 Colors Effect | 0 | Safe |
| | | 255 | 6 Colors Effect |
| 12 | Focus | 0 --> 255 | 0% to 100% Focus |
| 13 | Pan | 0 --> 255 | 540° Pan |
| 14 | Pan Fine | 0 --> 255 | Pan Fine |
| 15 | Tilt | 0 --> 255 | 270° Tilt |
| 16 | Tilt Fine | 0 --> 255 | Tilt Fine |
| 17 | Pan/Tilt Speed | 0 --> 255 | Pan/Tilt Speed |
| 18 | Reset | 0 --> 25 | Safe |
| | | 26 --> 76 | Effect Reset |
| | | 77 --> 127 | Pan/Tilt Reset |
| | | 128 --> 255 | Whole Unit Reset |
| 19 | Lamp | 0 --> 25 | Safe |
| | | 26 --> 100 | Lamp OFF |
| | | 101 --> 255 | Lamp ON |

Static Gobo Wheel

