



## Sparkly 480B

1 Mode 16

16 Ch
-------

Channel	Function	Value	Description
1	Colour Wheel	0	Open
		1 --> 128	Color Gradual Change
		129 --> 134	White
		135 --> 139	Deep Red
		140 --> 144	Blue
		145 --> 149	Yellow
		150 --> 154	Light Green
		155 --> 159	Pink
		160 --> 164	Light Blue
		165 --> 169	Magenta
		170 --> 174	Deep Green
		175 --> 179	Orange
		180 --> 184	CTB
		185 --> 189	Purple + Blue
		190 --> 220	Scroll CW Fast to Slow
		221 --> 225	Stop
		226 --> 255	Scroll CCW Slow to Fast
2	Strobe	0 --> 31	Closed
		32 --> 63	Open
		64 --> 95	Slow to Fast Strobe
		96 --> 127	Open
		128 --> 143	Fast to Slow Open Pulsation
		144 --> 159	Slow to Fast Close Pulsation
		160 --> 191	Open
		192 --> 223	Slow to Fast Random Strobe
		224 --> 255	Open
		3	Dimmer

		0	Open
		1 --> 3	Gobo 1
		4 --> 7	Gobo 2
		8 --> 12	Gobo 3
		13 --> 16	Gobo 4
		17 --> 20	Gobo 5
		21 --> 24	Gobo 6
		25 --> 29	Gobo 7
		30 --> 33	Gobo 8
		34 --> 37	Gobo 9
		38 --> 41	Gobo 10
		42 --> 46	Gobo 11
		47 --> 50	Gobo 12
		51 --> 54	Gobo 13
		55 --> 58	Gobo 14
		59 --> 63	Gobo 15
		64 --> 67	Gobo 16
		68 --> 71	Gobo 17
		72 --> 113	Fast to Slow CW Rotation
		114 --> 117	Stop
		118 --> 159	Slow to Fast CCW Rotation
		160 --> 165	Slow to Fast Gobo 1 Shake
		166 --> 170	Slow to Fast Gobo 2 Shake
		171 --> 176	Slow to Fast Gobo 3 Shake
		177 --> 181	Slow to Fast Gobo 4 Shake
		182 --> 187	Slow to Fast Gobo 5 Shake
		188 --> 193	Slow to Fast Gobo 6 Shake
		194 --> 198	Slow to Fast Gobo 7 Shake
		199 --> 204	Slow to Fast Gobo 8 Shake
		205 --> 209	Slow to Fast Gobo 9 Shake
		210 --> 215	Slow to Fast Gobo 10 Shake
		216 --> 220	Slow to Fast Gobo 11 Shake
		221 --> 226	Slow to Fast Gobo 12 Shake
		227 --> 232	Slow to Fast Gobo 13 Shake
		233 --> 237	Slow to Fast Gobo 14 Shake
		238 --> 243	Slow to Fast Gobo 15 Shake
		244 --> 248	Slow to Fast Gobo 16 Shake
		249 --> 255	Slow to Fast Gobo 17 Shake
4	Gobo Wheel		
5	Empty	0 --> 255	Empty
6	Empty	0 --> 255	Empty

7	Prism	<i>Prism Position Mode</i>	
		0 --> 5	Safe
		6 --> 25	Prism 1
		26 --> 50	Prism 2
		51 --> 75	Prism 3
		76 --> 100	Prism 4
		101 --> 125	Prism 5
		<i>Prism Rotation Mode</i>	
		126 --> 150	Prism 1
		151 --> 175	Prism 2
		176 --> 200	Prism 3
		201 --> 225	Prism 4
		226 --> 255	Prism 5
		8	Prism Rotation
0 --> 255	Index		
<i>Rotation Mode</i>			
0 --> 1	Safe		
2 --> 127	CW Fast to Slow Rotation		
128 --> 129	Stop		
9	Frost	0 --> 64	Safe
		65 --> 255	0% to 100% Frost
10	Focus	0 --> 255	0% to 100% Focus
11	Pan	0 --> 255	540° Pan
12	Pan Fine	0 --> 255	Pan Fine
13	Tilt	0 --> 255	270° Tilt
14	Tilt Fine	0 --> 255	Tilt Fine
15	Pan/Tilt Speed	0 --> 255	Pan/Tilt Speed
16	Control	0 --> 19	Safe
		20 --> 24	Energy Saving Mode (360W)
		25 --> 29	Normal Mode (440W)
		30 --> 129	Empty
		130 --> 139	Lamp ON
		140 --> 149	Pan/Tilt Reset
		150 --> 159	Empty
		160 --> 169	Small Motors Reset
		170 --> 199	Empty
		200 --> 209	Whole Unit Reset
		210 --> 229	Empty
		230 --> 239	Lamp OFF
		240 --> 255	Empty

# Static Gobo Wheel

