

XL-230

XL-230
2 Modes 16 - 20

16 Ch

Channel	Function	Value	Description
1	Colour Wheel	0	Open
		5	Open + Red
		10	Red
		13	Red + Orange
		18	Orange
		22	Orange + Magenta
		26	Magenta
		30	Magenta + Cyan
		35	Cyan
		39	Cyan + Light Pink
		43	Light Pink
		47	Light Pink + Pink
		52	Pink
		56	Pink + Light Green
		60	Light Green
		64	Light Green + Yellow
		69	Yellow
		73	Yellow + Lavender
		77	Lavender
		82	Lavender + Blue
		86	Blue
		90	Blue + CTB
		94	CTB
		99	CTB + Dark Blue
		103	Dark Blue
		107	Dark Blue + Green
		111	Green
		116	Green + CTO
		120	CTO
		124	CTO + Open
128 --> 255	Slow to Fast Scroll Rotation		

2	Strobe	0 --> 3	Closed
		4 --> 103	Slow to Fast Strobe
		104 --> 107	Open
		108 --> 207	Slow to Fast Pulsation
		208 --> 212	Open
		213 --> 225	Random Slow Strobe
		226 --> 238	Random Medium Strobe
		239 --> 251	Random Fast Strobe
		252 --> 255	Open
3	Dimmer	0 --> 255	0% to 100% Dimmer
4	Gobo Wheel	0	Open
		5	Gobo 1
		10	Gobo 2
		15	Gobo 3
		18	Gobo 4
		20	Gobo 5
		25	Gobo 6
		30	Gobo 7
		35	Gobo 8
		38	Gobo 9
		40	Gobo 10
		45	Gobo 11
		50	Gobo 12
		55	Gobo 13
		58	Gobo 14
		60	Gobo 15
		65	Gobo 16
		70	Gobo 17
		72 --> 113	Slow to Fast CCW Rotation
		114 --> 117	Stop
		118 --> 159	Slow to Fast CW Rotation
		160 --> 166	Slow to Fast Gobo 2 Shake
		167 --> 172	Slow to Fast Gobo 3 Shake
		173 --> 179	Slow to Fast Gobo 4 Shake
		180 --> 185	Slow to Fast Gobo 5 Shake
		186 --> 191	Slow to Fast Gobo 6 Shake
		192 --> 198	Slow to Fast Gobo 7 Shake
		199 --> 204	Slow to Fast Gobo 8 Shake
		205 --> 211	Slow to Fast Gobo 9 Shake
		212 --> 217	Slow to Fast Gobo 10 Shake
218 --> 223	Slow to Fast Gobo 11 Shake		
224 --> 230	Slow to Fast Gobo 12 Shake		
231 --> 236	Slow to Fast Gobo 13 Shake		
237 --> 243	Slow to Fast Gobo 14 Shake		
244 --> 249	Slow to Fast Gobo 15 Shake		
250 --> 255	Slow to Fast Gobo 16 Shake		
5	Prism	0 --> 127	Safe
		128 --> 255	Prism Inserted

6	Prism Rotation	0 --> 127	Safe
		128 --> 190	Slow to Fast CW Rotation
		191 --> 192	Stop
		193 --> 255	Slow to Fast CCW Rotation
7	Effects	0 --> 255	Empty
8	Frost	0 --> 255	0% to 100% Frost
9	Focus	0 --> 255	0% to 100% Focus
10	Pan	0 --> 255	540° Pan
11	Pan Fine	0 --> 255	Pan Fine
12	Tilt	0 --> 255	270° Tilt
13	Tilt Fine	0 --> 255	Tilt Fine
14	Function	0 --> 255	Empty
15	Reset	0 --> 25	Unused Range
		26 --> 76	Effect Reset
		77 --> 127	Pan/Tilt Reset
		128 --> 255	Complete Reset
16	Lamp Control	0 --> 9	Unused Range
		10 --> 100	Lamp On
		101 --> 255	Lamp Off

20 Ch

Channel	Function	Value	Description
1	Colour Wheel	0	Open
		5	Open + Red
		10	Red
		13	Red + Orange
		18	Orange
		22	Orange + Magenta
		26	Magenta
		30	Magenta + Cyan
		35	Cyan
		39	Cyan + Light Pink
		43	Light Pink
		47	Light Pink + Pink
		52	Pink
		56	Pink + Light Green
		60	Light Green
		64	Light Green + Yellow
		69	Yellow
		73	Yellow + Lavender
		77	Lavender
		82	Lavender + Blue
86	Blue		
90	Blue + CTB		
94	CTB		
99	CTB + Dark Blue		
103	Dark Blue		
107	Dark Blue + Green		

		111	Green
		116	Green + CTO
		120	CTO
		124	CTO + Open
		128 --> 255	Slow to Fast Scroll Rotation
2	Strobe	0 --> 3	Closed
		4 --> 103	Slow to Fast Strobe
		104 --> 107	Open
		108 --> 207	Slow to Fast Pulsation
		208 --> 212	Open
		213 --> 225	Random Slow Strobe
		226 --> 238	Random Medium Strobe
		239 --> 251	Random Fast Strobe
		252 --> 255	Open
3	Dimmer	0 --> 255	0% to 100% Dimmer
4	Gobo Wheel	0	Open
		5	Gobo 1
		10	Gobo 2
		15	Gobo 3
		18	Gobo 4
		20	Gobo 5
		25	Gobo 6
		30	Gobo 7
		35	Gobo 8
		38	Gobo 9
		40	Gobo 10
		45	Gobo 11
		50	Gobo 12
		55	Gobo 13
		58	Gobo 14
		60	Gobo 15
		65	Gobo 16
		70	Gobo 17
		72 --> 113	Slow to Fast CCW Rotation
		114 --> 117	Stop
		118 --> 159	Slow to Fast CW Rotation
		160 --> 166	Slow to Fast Gobo 2 Shake
		167 --> 172	Slow to Fast Gobo 3 Shake
		173 --> 179	Slow to Fast Gobo 4 Shake
		180 --> 185	Slow to Fast Gobo 5 Shake
		186 --> 191	Slow to Fast Gobo 6 Shake
		192 --> 198	Slow to Fast Gobo 7 Shake
		199 --> 204	Slow to Fast Gobo 8 Shake
		205 --> 211	Slow to Fast Gobo 9 Shake
		212 --> 217	Slow to Fast Gobo 10 Shake
		218 --> 223	Slow to Fast Gobo 11 Shake
224 --> 230	Slow to Fast Gobo 12 Shake		
231 --> 236	Slow to Fast Gobo 13 Shake		
237 --> 243	Slow to Fast Gobo 14 Shake		
244 --> 249	Slow to Fast Gobo 15 Shake		
250 --> 255	Slow to Fast Gobo 16 Shake		

5	Prism	0 --> 127	Safe
		128 --> 255	Prism Inserted
6	Prism Rotation	0 --> 127	Safe
		128 --> 190	Slow to Fast CW Rotation
		191 --> 192	Stop
		193 --> 255	Slow to Fast CCW Rotation
7	Effects	0 --> 255	Empty
8	Frost	0 --> 255	0% to 100% Frost
9	Focus	0 --> 255	0% to 100% Focus
10	Pan	0 --> 255	540° Pan
11	Pan Fine	0 --> 255	Pan Fine
12	Tilt	0 --> 255	270° Tilt
13	Tilt Fine	0 --> 255	Tilt Fine
14	Function	0 --> 255	Empty
15	Reset	0 --> 25	Unused Range
		26 --> 76	Effect Reset
		77 --> 127	Pan/Tilt Reset
		128 --> 255	Complete Reset
16	Lamp Control	0 --> 9	Unused Range
		10 --> 100	Lamp On
		101 --> 255	Lamp Off
17	Pan-Tilt Time	0 --> 255	0% to 100%
18	Colour Time	0 --> 255	0% to 100%
19	Beam Time	0 --> 255	0% to 100%
20	Gobo Time	0 --> 255	0% to 100%

Static Gobo Wheel

