

FLASH 54

Number	Description	Qty
1	Base	1
2	Quick lock	4
3	Base cover	1
4	Power supply	1
5	Power supply support	1
6	Silicone pad	2
7	Display transparent panel	1
8	Display	1
9	Display support	1
10	Base case	1
11	Metal vent	2
12	Cooling fin	1
13	LED board	1
14	Lens	36
15	Lens holder	1
16	Waterproof rubber ring	1
17	Tempered glass	1
18	Front cover	1
19	Fan	3
20	Fan cover	1
21	DMX out	1
22	Power out	1
23	Wireless receiver	1
24	Model socket	1
25	Power in	1
26	Side cover waterproof rubber ring	2
27	Side cover	2
28	Filter	1
29	M8 rotary knob	2
30	Decorative	2
31	Filter support	1
32	Filter board	1
33	Main support	1

