

Flash 200

1 Mode 4

4 CH

Channel	Function	Value	Description
1	Master Dimmer	0 --> 255	0% to 100% Dimmer
2	H1 Dimmer	0 --> 255	0% to 100% Dimmer
3	H2 Dimmer	0 --> 255	0% to 100% Dimmer
4	Strobe	0	Open
		1 --> 255	Slow to Fast Strobe