

Flash 5

2 Modes 1 - 2

1 CHs

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer

2 CHs

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Strobe	0	Open
		1 --> 255	Slow to Fast Strobe