

## MD1

**1 Mode 18**

**18 CH**

Channel	Function	Value	Description
1	Pan	0 --> 255	540° Pan
2	Pan Rotation	0 --> 55	Safe
		56 --> 155	Slow to Fast Continuous Rotation
		156 --> 255	Slow to Fast Continuous Reverse Rotation
3	Pan Fine	0 --> 255	Pan Fine
4	Tilt	0 --> 255	270° Tilt
5	Tilt Rotation	0 --> 55	Safe
		56 --> 155	Slow to Fast Continuous Rotation
		156 --> 255	Slow to Fast Continuous Reverse Rotation
6	Tilt Fine	0 --> 255	Tilt Fine
7	P/T Speed	0 --> 255	0% to 100% P/T Speed
8	Dimmer	0 --> 255	0% to 100% Dimmer
9	Shutter Function	0 --> 55	Open
		56 --> 155	Slow to Fast Strobe (1-25 Hz)
		156 --> 205	Random Strobe
		206 --> 255	Pulse Strobe
10	Red	0 --> 255	0% to 100% Red LEDs
11	Green	0 --> 255	0% to 100% Green LEDs
12	Blue	0 --> 255	0% to 100% Blue LEDs
13	White	0 --> 255	0% to 100% White LEDs
14	Color Macro	0 --> 5	Effect 1
		6 --> 11	Effect 2
		12 --> 17	Effect 3
		18 --> 23	Effect 4
		24 --> 28	Effect 5
		29 --> 34	Effect 6
		35 --> 40	Effect 7
		41 --> 46	Effect 8
		47 --> 51	Effect 9
		52 --> 57	Effect 10
		58 --> 63	Effect 11
		64 --> 69	Effect 12
		70 --> 75	Effect 13
		76 --> 80	Effect 14

15	Dynamic Macro	0 --> 49	Effect 1
		50 --> 99	Effect 2
		100 --> 149	Effect 3
		150 --> 255	Effect 4
16	Speed	0 --> 255	Macro Speed
17	Mode	0 --> 49	Safe
		50 --> 99	Colour Macro
		100 --> 149	Dynamic Effect
		150 --> 199	Auto
18	Reset	200 --> 255	Sound
		0 --> 250	Safe
		251 --> 255	Reset All