

## XL 30

### 2 Modes 4 - 8

#### 4 CHs

Channel	Function	Value	Description
1	Red	0 --> 255	0% to 100% Red LEDs
2	Green	0 --> 255	0% to 100% Green LEDs
3	Blue	0 --> 255	0% to 100% Blue LEDs
4	White	0 --> 255	0% to 100% White LEDs

#### 8 CHs

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Red	0 --> 255	0% to 100% Red LEDs
3	Green	0 --> 255	0% to 100% Green LEDs
4	Blue	0 --> 255	0% to 100% Blue LEDs
5	White	0 --> 255	0% to 100% White LEDs
6	Strobe	0 --> 255	Slow to Fast Strobe
7	Function	0 --> 50	Safe
		51 --> 100	Different Colors Output
		101 --> 150	Colors Jump Change
		151 --> 200	Colors Gradate
		201 --> 250	Colors Pulse Change
		251 --> 255	Sound-Active
8	Speed	0 --> 255	Slow to Fast Speed Function