

## Blade G850

### 2 Modes 7 - 22

#### 7 CHs

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Strobe	0 --> 15	Open
		16 --> 95	Slow to Fast Strobe (1-25 Hz)
		96 --> 175	Strobe
		176 --> 255	Random Strobe
3	Tilt	0 --> 255	180° Tilt
4	Tilt Fine	0 --> 255	Tilt Fine
5	Speed	0 --> 255	Tilt Speed
6	Function	0 --> 29	Off
		30 --> 99	Laser On
		100 --> 199	LED On
		200 --> 255	Laser + LED On
7	Mode	0 --> 30	Safe
		31 --> 200	Auto Mode
		201 --> 255	Sound Mode

#### 22 CHs

Channel	Function	Value	Description
1	Dimmer	0 --> 255	0% to 100% Dimmer
2	Strobe	0 --> 15	Open
		16 --> 95	Slow to Fast Strobe (1-25 Hz)
		96 --> 175	Strobe
		176 --> 255	Random Strobe
3	Tilt	0 --> 255	180° Tilt
4	Tilt Fine	0 --> 255	Tilt Fine
5	Speed	0 --> 255	Tilt Speed

6	Macros	0 --> 15	Safe
		16 --> 35	Effect 1
		36 --> 55	Effect 2
		56 --> 75	Effect 3
		76 --> 95	Effect 4
		96 --> 115	Effect 5
		116 --> 135	Effect 6
		136 --> 155	Effect 7
		156 --> 175	Effect 8
		176 --> 195	Effect 9
		196 --> 255	Effect 10
7	Macro Speed	0 --> 255	Macro Speed
8	Laser 1	0 --> 127	Off
		128 --> 255	On
9	Laser 2	0 --> 127	Off
		128 --> 255	On
10	Laser 3	0 --> 127	Off
		128 --> 255	On
11	Laser 4	0 --> 127	Off
		128 --> 255	On
12	Laser 5	0 --> 127	Off
		128 --> 255	On
13	Laser 6	0 --> 127	Off
		128 --> 255	On
14	Laser 7	0 --> 127	Off
		128 --> 255	On
15	Laser 8	0 --> 127	Off
		128 --> 255	On
16	LED 1 Dimmer	0 --> 255	0% to 100% Dimmer
17	LED 2 Dimmer	0 --> 255	0% to 100% Dimmer
18	LED 3 Dimmer	0 --> 255	0% to 100% Dimmer
19	LED 4 Dimmer	0 --> 255	0% to 100% Dimmer
20	LED 5 Dimmer	0 --> 255	0% to 100% Dimmer
21	LED 6 Dimmer	0 --> 255	0% to 100% Dimmer
22	LED 7 Dimmer	0 --> 255	0% to 100% Dimmer