



Razor R6500

3 Modes 9 - 19 - 19

9 CHs

Channel	Function	Value	Description
1	Tilt	0 --> 255	240° Bar Tilt
2	Tilt Speed	0 --> 255	Tilt Speed
3	Pan	0 --> 255	90° Diode Pan
4	Pan Speed	0 --> 255	Pan Speed
5	Dimmer	0 --> 127	Off
		128 --> 255	On
6	Strobe	0 --> 15	Close
		16 --> 30	Open
		31 --> 90	Slow to Fast Variable Strobe
		91 --> 105	Open
		106 --> 165	Slow to Fast Pulse
		166 --> 180	Open
		181 --> 240	Slow to Fast Random Strobe
		241 --> 255	Open
7	Laser 1-6	0 --> 127	Off
		128 --> 255	On
8	Macros	0 --> 10	Safe
		11 --> 26	Effect 1
		27 --> 32	Effect 2
		33 --> 48	Effect 3
		49 --> 64	Effect 4
		65 --> 80	Effect 5
		81 --> 96	Effect 6
		97 --> 112	Effect 7
		113 --> 128	Effect 8
		129 --> 144	Effect 9
		145 --> 160	Effect 10
		161 --> 176	Effect 11
		177 --> 192	Effect 12
		193 --> 208	Effect 13
		209 --> 224	Effect 14
		225 --> 240	Auto 1
		241 --> 250	Auto 2
		251 --> 255	Reset
9	Speed / Mode	0 --> 250	Macro Speed
		251 --> 255	Sound Mode

19 CHs (1)

Channel	Function	Value	Description
1	Tilt	0 --> 255	240° Bar Tilt

2	Tilt Speed	0 --> 255	Tilt Speed
3	Pan 1	0 --> 255	90° Diode Pan
4	Pan 2	0 --> 255	90° Diode Pan
5	Pan 3	0 --> 255	90° Diode Pan
6	Pan 4	0 --> 255	90° Diode Pan
7	Pan 5	0 --> 255	90° Diode Pan
8	Pan 6	0 --> 255	90° Diode Pan
9	Pan Speed	0 --> 255	Pan Speed
10	Dimmer	0 --> 127	Off
		128 --> 255	On
11	Strobe	0 --> 15	Close
		16 --> 30	Open
		31 --> 90	Slow to Fast Variable Strobe
		91 --> 105	Open
		106 --> 165	Slow to Fast Pulse
		166 --> 180	Open
		181 --> 240	Slow to Fast Random Strobe
		241 --> 255	Open
		0 --> 127	Off
12	Laser 1	128 --> 255	On
13	Laser 2	0 --> 127	Off
14	Laser 3	128 --> 255	On
15	Laser 4	0 --> 127	Off
16	Laser 5	128 --> 255	On
17	Laser 6	0 --> 127	Off
		128 --> 255	On

18	Macros	0 --> 10	Safe
		11 --> 26	Effect 1
		27 --> 32	Effect 2
		33 --> 48	Effect 3
		49 --> 64	Effect 4
		65 --> 80	Effect 5
		81 --> 96	Effect 6
		97 --> 112	Effect 7
		113 --> 128	Effect 8
		129 --> 144	Effect 9
		145 --> 160	Effect 10
		161 --> 176	Effect 11
		177 --> 192	Effect 12
		193 --> 208	Effect 13
		209 --> 224	Effect 14
		225 --> 240	Auto 1
		241 --> 250	Auto 2
		251 --> 255	Reset
19	Speed / Mode	0 --> 250	Macro Speed
		251 --> 255	Sound Mode

19 CHs (2)

Channel	Function	Value	Description
1	Pan 1	0 --> 255	90° Diode Pan
2	Laser 1	0 --> 127	Off
		128 --> 255	On
3	Pan 2	0 --> 255	90° Diode Pan
4	Laser 2	0 --> 127	Off
		128 --> 255	On
5	Pan 3	0 --> 255	90° Diode Pan
6	Laser 3	0 --> 127	Off
		128 --> 255	On
7	Pan 4	0 --> 255	90° Diode Pan
8	Laser 4	0 --> 127	Off
		128 --> 255	On
9	Pan 5	0 --> 255	90° Diode Pan
10	Laser 5	0 --> 127	Off
		128 --> 255	On
11	Pan 6	0 --> 255	90° Diode Pan
12	Laser 6	0 --> 127	Off
		128 --> 255	On

13	Dimmer	0 --> 127	Off
		128 --> 255	On
14	Strobe	0 --> 15	Close
		16 --> 30	Open
		31 --> 90	Slow to Fast Variable Strobe
		91 --> 105	Open
		106 --> 165	Slow to Fast Pulse
		166 --> 180	Open
		181 --> 240	Slow to Fast Random Strobe
		241 --> 255	Open
		0 --> 255	240° Bar Tilt
15	Tilt	0 --> 255	240° Bar Tilt
16	Tilt Speed	0 --> 255	Tilt Speed
17	Pan Speed	0 --> 255	Pan Speed
18	Macros	0 --> 10	Safe
		11 --> 26	Effect 1
		27 --> 32	Effect 2
		33 --> 48	Effect 3
		49 --> 64	Effect 4
		65 --> 80	Effect 5
		81 --> 96	Effect 6
		97 --> 112	Effect 7
		113 --> 128	Effect 8
		129 --> 144	Effect 9
		145 --> 160	Effect 10
		161 --> 176	Effect 11
		177 --> 192	Effect 12
		193 --> 208	Effect 13
		209 --> 224	Effect 14
		225 --> 240	Auto 1
19	Speed / Mode	241 --> 250	Auto 2
		251 --> 255	Reset
19	Speed / Mode	0 --> 250	Macro Speed
		251 --> 255	Sound Mode